

Steps to connect GlassOuse with iPhone updated to iOS 13

First, here is the list of iPhones which will receive new iOS 13 Update:

- iPhone 6s
- iPhone 6s Plus
- iPhone SE
- iPhone 7
- iPhone 7 Plus
- iPhone 8
- iPhone 8 Plus
- iPhone X
- iPhone XR
- iPhone XS
- iPhone XS Max
- iPhone 11
- iPhone 11 Pro
- iPhone 11 Pro Max

And here are the steps:



1. Open Settings, then choose "Accessibility".





•	中国移动 🗢	10:38	Q 🔊 86	% 🔳		
•	Accessibility	Touch				
	AssistiveTouch		Of	f >		
	AssistiveTouch allows you difficulty touching the scru accessory.	to use your iPh een or if you rec	one if you have quire an adaptive			
	Reachability			\supset		
	Double-tap the home butt into reach.	ton to bring the	top of the screer	1		
	3D & Haptic Touch		Or	1 >		
	When 3D Touch is on, you can press on the display using different degrees of pressure to reveal content previews, actions and contextual menus.					
	Touch Accommodati	ions	Of	f>		
	If you have trouble using the touch screen, adjust the following settings to change how the screen will respond to touches.					
	Shake to Undo			\Box		
	If you tend to shake your i Shake to Undo to prevent	Phone by accid the Undo alert	ent, you can disa from appearing.	ble		

Vibration

3. Click

"AssistiveTouch" bar near the top of the screen.



II 中国移动 🗢 10:38	@ 🕫 86% 🔳)
Couch AssistiveTo	uch
AssistiveTouch	
AssistiveTouch allows you to use you difficulty touching the screen or if yo accessory.	ur iPhone if you have bu require an adaptive
Customize Top Level Menu	>
CUSTOM ACTIONS	
Single-Tap	Open Menu 🗦
Double-Tap	None >
Long Press	None >
3D Touch	Home >
Custom actions allow you to interact AssistiveTouch icon without opening CUSTOM GESTURES	directly with the the menu.
Create New Gesture	>
Custom gestures allow you to record activated from Custom in the Menu.	gestures that can be
Idle Opacity	40% >

山山国移动 🗢	10:41	
□□中国修动 マ	10.41	9 7 85% –
< Touch	AssistiveTouch	
AssistiveTouch icor	n without opening the menu.	
CUSTOM GESTUR	ES	
Create New Ca	atura	<u>,</u>
Create New Ge	sture	/
Custom gestures a activated from Cus	llow you to record gestures t tom in the Menu.	hat can be
Idle Opacity		40% >
POINTER DEVICES	J	
Devices		>
Devices Mouse Keys		>
Devices Mouse Keys Pointer Style		> > >
Devices Mouse Keys Pointer Style Show Onscreen	n Keyboard	> > >
Devices Mouse Keys Pointer Style Show Onscreen Always Show M	n Keyboard Ienu	> > >
Devices Mouse Keys Pointer Style Show Onscreed Always Show M Show the Assistive is connected.	n Keyboard Ienu Touch menu when a pointer (> > device
Devices Mouse Keys Pointer Style Show Onscreen Always Show M Show the Assistive is connected. TRACKING SPEED	n Keyboard 1enu Touch menu when a pointer o	> > device
Devices Mouse Keys Pointer Style Show Onscreen Always Show M Show the Assistive is connected. TRACKING SPEED	n Keyboard Ienu Touch menu when a pointer o	> > device

Drag Lock

 Turn ON the "AssistiveTouch" toggle near the top of the screen.

 Under Assistive Touch only, scroll down to "Pointer Devices" and tap on Devices.







Soon after connection a circular pointer will appear on the screen which you can navigate via GlassOuse.

Always Show Menu		
Show the AssistiveTouch menu when a pointer device is connected.	9	v
TRACKING SPEED		י ר
æ —————	Ŝ	t c
Drag Lock	\bigcirc	2
		A

Also you can control your cursor speed from "**Tracking Speed**" under Assistive Touch panel.

